

Distribution pipelines
Trunk main pipelines
Transmission main pipelines

PINPOINTING
CORRELATION
PRELOCATING
PIPE SEARCHING
MONITORING

PipeMic[®] XL/XXL

Precise leakage detection



DETECTS LEAKAGES WITH UNPRECEDENTED PRECISION

9 MILLIMETRE FIBRE OPTIC CABLE

CAN BE PUSHED ON LONGER DISTANCES IN LARGER PIPES

AVAILABLE WITH UP TO 300 METRES OF CABLE

3-IN-1-FUNCTION:

ACOUSTIC LEAKAGE DETECTION + PIPE DETECTION + END DETECTION



FAST
GROUPE CLAIRE

STANDARD SOLUTIONS

 EQUIPMENT

Main unit XL/XXL



Accessory case




Desinfection liquid



BT-headphones



Pipe locator
(different models
available)



Hose piece

9 V battery



BT-speaker



Banana cable for connecting
PipeMic® with pipe locator



Charging
accessories



BT-Dongel for
Aqua M300
(page 36,37)



GK-couplers with inner
and outer thread

Insertion guide



 APPLICATION

- Inserting the probe through the manhole/flange, or insertion guide into the pressurized pipe
- Determining the position of the leakage through maximum noise indication
- Connecting the pipe locator with the banana plug and conducting the search for the pipe / end detection
- Integrated disinfection appliance for safe usage

